

Feature Codes

**Note: If you have hosted service and control your forwards through Your Phone system you cannot use these Feature Codes. Contact support for assistance.*

H3- Users on Analog Conversion, PRI, RBS/T1, or SIP trunk service. dials a configuration-affecting code (such as *77), the configuration change will apply to the entire trunk, not just to the DID that placed the call.

Code	Name	Description
*11	Group Call Pickup	Pick up an incoming call to a phone in your call pickup group (if subscribed & configured)
*12	Directed Call Pickup	Pick up a call ringing on another user's phone (if subscribed & configured)
*67	Disable Calling Name Delivery for Single Call	Dial *67 and then the number (*6716467508830) to block calling name delivery for a single call
*69	Last Call Return	Returns the last incoming call if possible
*72	Enable Unconditional Call Forwarding	Immediately forward all calls to the number specified. Dial *72 followed by the number you wish to forward to as you would normally dial. A call will be placed to the forward destination for verification so you must stay on the line for it to be answered. Example *7216467508830. Deactivated by *73
*73	Disable Unconditional Call Forwarding	Disable call forwarding activated by *72
*77	Enabled Anonymous Call Rejection	Rejects all calls which do not send a calling number such as blocked or anonymous
*78	Enable Do Not Disturb (DND)	Rejects all incoming calls with an announcement
*79	Disable Do Not Disturb (DND)	Disable DND service activated by *78
*87	Disabled Anonymous Call Rejection	Turns off Anonymous Call Rejection enabled by *77
*98	Voice Mail Access	If subscribed to voice mail you can access it with this feature code. You will be prompted for your PIN code.